




INPUT CC NUMBERS FOR DIRECT PARAMETER SETTING




OUTPUT CC NUMBERS - DIRECT KNOB POSITION



MIDI NOTE INPUT



ENTER/LEAVE ADVANCED SETTINGS



SET MIDI CLOCK DIVIDER

