

Pizza BASIL DELAY

Release Notes

basil 1.00 (RANGE light ON at startup)
release version

HOW TO UPDATE:

1. Connect a micro USB cable to the Basil Pizza module
2. Hold the DELAY button and plug the USB into your computer
3. Basil Pizza shows up as an external disk on your computer
4. Copy the pizza_basil_ *version*.uf2 file to this drive and wait for the Basil Pizza module to update and boot to normal operation
5. Disconnect the USB and install the Basil Pizza in your rack

Pizza shows the firmware version by a static light of the LEDs at startup:

- The release firmware version has the RANGE light ON.